

Assembly Tools

EL OCHITO® ASSEMBLY KITS AND TOOLS

Assembly Tools										
Contact PN	Inner Contact Crimp		Cable Shield Hex Crimp		Cable Shield Round Crimp			Key Alignment Tool	Ferrule Insertion Tool	Mating Tool
	Tool	Positioner	Tool	Hex Die	Tool	Positioner 1	Positioner 2			
858-003	809-015	859-101	809-129	859-007				600-236	600-242	600-263
858-004	809-015	859-101	809-129	859-007				600-235	600-242	600-264
858-005	809-015	859-101						600-236	600-242	600-263
858-006	809-015	859-101						600-235	600-242	600-264
858-009	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-010	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-014	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-015	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-016	809-015	859-101			809-134	859-184-2	859-184-3	600-236	600-242	600-263
858-017	809-015	859-101			809-134	859-184-1	859-184-2	600-235	600-242	600-264
858-026	809-015	859-101	809-129	859-007				600-236	600-242	
858-027	809-015	859-101	809-129	859-007				600-236	600-242	
858-028-01	809-015	859-101	809-129	859-007				600-236	600-242	600-263
858-028-02	809-015	859-101			809-134	859-184-2	859-184-3	600-236	600-242	600-263
858-029-01	809-015	859-101	809-129	859-007				600-235	600-242	600-264
858-029-02	809-015	859-101			809-134	859-184-1	859-184-2	600-235	600-242	600-264
858-030-02	809-015	859-101	809-129	859-007				600-236	600-242	600-263
858-031-02	809-015	859-101	809-129	859-007				600-236	600-242	600-264
858-035-01	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-035-02	809-015	859-101	809-129	859-186				600-243	600-242	600-266
858-037	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-038-01	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-038-02	809-015	859-101	809-129	859-186				600-244	600-242	600-265
858-039	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-042	809-015	859-101						600-235	600-242	600-267
858-043	809-015	859-101						600-274	600-242	600-264
858-045	809-015	859-101	809-129	859-007				600-274	600-242	600-267
858-046	809-015	859-101	809-129	859-007				600-235	600-242	600-264
858-047-01	809-015	859-101	809-129	859-007				600-274	600-242	600-267
858-047-02	809-015	859-101			809-134	859-184-2	859-184-3	600-274	600-242	600-267
858-048-01	809-015	859-101	809-129	859-007				600-235	600-242	600-264
858-048-02	809-015	859-101			809-134	859-184-2	859-184-3	600-235	600-242	600-264
858-049	809-015	859-101	809-129	859-007				600-274	600-242	600-267
858-050	809-015	859-101	809-129	859-007				600-235	600-242	600-267
858-051	809-015	859-101						600-274	600-242	600-264
858-052	809-015	859-101						600-235	600-242	600-267
858-055	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-056	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-057-01	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-057-02	809-015	859-101	809-129	859-186				600-244	600-242	600-265

Assembly Tools

Assembly Tools										
Contact PN	Inner Contact Crimp		Cable Shield Hex Crimp		Cable Shield Round Crimp			Key Alignment Tool	Ferrule Insertion Tool	Mating Tool
	Tool	Positioner	Tool	Hex Die	Tool	Positioner 1	Positioner 2			
858-058-01	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-058-02	809-015	859-101	809-129	859-186				600-243	600-242	600-266
858-059	809-015	859-101	809-129	859-007				600-244	600-242	600-265
858-060	809-015	859-101	809-129	859-007				600-243	600-242	600-266
858-061	809-015	859-101						600-244	600-242	600-265
858-062	809-015	859-101						600-243	600-242	600-266
858-063	809-015	859-101						600-236	600-242	600-263
858-064	809-015	859-101						600-235	600-242	600-264
858-065	809-015	859-101						600-236	600-242	600-267
858-066	809-015	859-101						600-235	600-242	600-264
858-067	809-015	859-101						600-274	600-242	600-267
858-068	809-015	859-101						600-235	600-242	600-264
858-069	809-015	859-101						600-236	600-242	600-263
858-070	809-015	859-101						600-235	600-242	600-264
858-071	809-015	859-101						600-236	600-242	600-267
858-072	809-015	859-101						600-235	600-242	600-264
858-073	809-015	859-101						600-236	600-242	600-267
858-074	809-015	859-101						600-235	600-242	600-264

Inner Contact Crimp Tools		Cable Shield Crimp Tools				Removal Tool	
809-015 (M22520/2-01)	859-101 (K1906)	809-129 (M22520/5-01)	859-007 (M22520/5-45)	859-186	859-134 (GS206)	859-184	859-049 (M81969/14-12)

Key Alignment Tools*		Ferrule Insertion Tool	Jumper Cable Mating Adapters**	
600-235 & 600-243 Socket contact	600-236, -244, & -274 Pin contact	600-242	600-264 & -266 Socket Contact	600-263, -265, & -267 Pin Contact

* Only for use when assembling El Ochito contacts. Consult factory for available alignment inspection tools for existing assemblies.

** See page 50 for details